

Instruction manual

i3 TrackPor M (monitoring device for asbestos analysis)



DO NOT remove the white protective cap from the monitor cassette outlet.



Slowly unscrew the INLET cap on the i3 TrackPor M monitor cassette or remove it by slightly tipping it (see the label on the i3 TrackPor M monitor)

NOTE:

Jerky pulling off with a missing housing white protective cap can create a negative pressure in the monitor, which can cause membranes to ripple or even them to tear. At the same time, pulling off the lower black cap (on the INLET) prevents the creation of negative pressure.



Use the ready-to-use i3 TrackPor M monitor in accordance with the relevant VDI standard.