



## Catalog of Accessories

Your Companion  
Life Science Filtration



## Table of contents

Determining the correct thread	p. 3
Selecting the appropriate accessories	p. 4
Accessories i3 ONE	pp. 5-15
Accessories i3 TWO	pp. 16-17
Accessories i3 FOUR	pp. 18-22
Accessories i3 FIVE	pp. 23-29
Overview of accessories	pp. 30-32

3

ONE

## Determining the correct thread

In order to determine the correct thread, detach the aerator from the water tap, the shower head from the shower hose or the flex hose from the angle valve. You will then already see whether it is a male or female thread (to which the accessory is to be mounted).

Water taps usually have a **fine thread**, here the threads are close together.

A **coarse thread** or pipe thread is always found on hoses, such as the shower hose. Here the threads are further apart.

### Measuring a male thread

Using a ruler or calipers, measure the outside diameter of the thread as shown in the following figure and read the measurement:



### Measuring a female thread

Using a ruler or calipers, measure the inside diameter of the thread as shown in the following figure and read the dimension:



## Selecting the appropriate accessories


Once you have determined the thread (male or female), differentiated between fine or coarse thread, and you know the thread dimension, you can then use the following overview to select the appropriate accessories for your i3 sterile filter.

Fine pitch thread e.g. water tap					
Male thread			Female thread		
Outside diameter*	Thread	Required i3 accessories	Inside diameter*	Thread	Required i3 accessories
16.3 mm	M16.5 M	page 7	14.9 mm	M16 F	page 6
17.9 mm	M18 M	page 8	20.9 mm	M22 F	page 12
18.3 mm	M18.5 M	page 9			
19.9 mm	M20 M	page 10			
21.3 mm	M21.5 M	page 11			
23.9 mm	M24 M	page 13			
26.9 mm	M28 M	page 14			

Coarse thread e.g. shower hose					
Male thread			Female thread		
Outside diameter*	Thread	Required i3 accessories	Inside diameter*	Thread	Required i3 accessories
16.7 mm	G3/8" M	page 19, 24	15.2 mm	G3/8" F	---
20.8 mm	G1/2" M	page 17, 20, 25	19 mm	G1/2" F	page 21,26
26.3 mm	G3/4" M	page 27	24.3 mm	G3/4" F	page 28

\*: measured by you

## Accessories i3 ONE






## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M16 F Connector ONE (AS)</b>
<b>Item number:</b>	S206015
<b>Description:</b>	Quick release coupling with M16x1 female thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M16x1 male thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M22 F Connector ONE (AS) 1x M16 F Adaptor 1x M22 flat gasket 1x M16 flat gasket
<b>Installation:</b>	The assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Item number S206015nAS.



## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M16.5 M Connector ONE (AS)</b>
<b>Item number:</b>	S206024
<b>Description:</b>	Quick release coupling with M16.5x1 male thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M16.5x1 female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M22 F Connector ONE (AS) 1x M16.5 M Adaptor 1x M22 flat gasket
<b>Installation:</b>	The assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Item number S206024nAS.



## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M18 M Connector ONE (AS)</b>
<b>Item number:</b>	S206013
<b>Description:</b>	Quick release coupling with M18x1 male thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M18x1 female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M22 F Connector ONE (AS) 1x M16.5 M Adaptor 1x M22 flat gasket 1x M18 flat gasket
<b>Installation:</b>	The assembly and installation of the components must be carried out by qualified technical personnel



\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Item number S206013nAS.






## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M18.5 M Connector ONE (AS)</b>
<b>Item number:</b>	S206012
<b>Description:</b>	Quick release coupling with M18.5x1 male thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M18.5x1 female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M22 F Connector ONE (AS) 1x M18.5 M Adaptor 1x M22 flat gasket
<b>Installation:</b>	The assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Item number S206012nAS.



## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M20 M Connector ONE (AS)</b>
<b>Item number:</b>	S206020
<b>Description:</b>	Quick release coupling with M20x1 male thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M20x1 female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M22 F Connector ONE (AS) 1x M20 M Adaptor 1x M22 flat gasket
<b>Installation:</b>	The assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Item number S206020nAS.



## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M21.5 M Connector ONE (AS)</b>
<b>Item number:</b>	S206011
<b>Description:</b>	Quick release coupling with M21.5x1 male thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M21.5x1 female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M22 F Connector ONE (AS) 1x M21.5 M Adaptor 1x M22 flat gasket
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Part number S206011nAS.



## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M22 F Connector ONE (AS)</b>
<b>Item number:</b>	2060000
<b>Description:</b>	Quick release coupling with M22x1 female thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M22x1 male thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M22 F Connector ONE (AS) 1x M22 flat gasket
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Part number 2060020.



## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M24 M Connector ONE (AS)</b>
<b>Item number:</b>	2060001
<b>Description:</b>	Quick release coupling with M24x1 male thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M24x1 female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M24 M Connector (AS) 1x M24 flat gasket
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Part number 206021.



## Accessories i3 ONE

### Water tap

<b>Designation:</b>	<b>M28 M Connector ONE (AS)</b>
<b>Item number:</b>	S206007
<b>Description:</b>	Quick release coupling with M28x1 male thread AquaStopp function* included
<b>Compatibility:</b>	i3 ONE sterile filter
<b>Application:</b>	Water tap with M28x1 female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x M24 M Connector ONE (AS) 1x M28 M Adaptor 1x M22 flat gasket 1x M28 flat gasket
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Part number 206021.




## Accessories i3 ONE

### Water tap


<b>Designation:</b>	<b>Sampling Adaptor</b>
<b>Item number:</b>	S2060018
<b>Description:</b>	Single use adaptor for taking water samples from the quick release coupling
<b>Compatibility:</b>	i3 ONE / i3 FOUR quick release couplings
<b>Application:</b>	Water sampling
<b>Material:</b>	POM
<b>Scope of delivery:</b>	10x Sampling adaptor



## Accessories i3 TWO








## Accessories i3 TWO


### Shower

<b>Designation:</b>	<b>G1/2" M Connector TWO (AS)</b>
<b>Item number:</b>	2060002
<b>Description:</b>	Quick release coupling with G1/2" male thread AquaStopp function* included
<b>Compatibility:</b>	i3 TWO connect sterile filter
<b>Application:</b>	Shower hose with G1/2" female thread
<b>Material:</b>	PSU (main body)
<b>Scope of delivery:</b>	1x G1/2" M Connector TWO (AS) 1x 1/2" flat gasket
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel



\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.  
Variant without AquaStopp: Part number 206022.

## Accessories i3 FOUR






## Accessories i3 FOUR

### Inline

<b>Designation:</b>	<b>G3/8" M Connector FOUR (AS)</b>
<b>Item number:</b>	2060005
<b>Description:</b>	Quick release coupling with G3/8" male thread AquaStopp function* included
<b>Compatibility:</b>	i3 FOUR inline filter
<b>Application:</b>	Dental units; ENT units; flexible tubing with G3/8" female thread
<b>Material:</b>	Chrome plated brass (main body)
<b>Scope of delivery:</b>	1x G3/8" M Connector FOUR (AS)
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.



## Accessories i3 FOUR

### Inline

<b>Designation:</b>	<b>G1/2" M Connector FOUR (nAS)</b>
<b>Part number:</b>	2060060
<b>Description:</b>	Quick release coupling with G1/2" male thread AquaStopp function* not included
<b>Compatibility:</b>	i3 FOUR inline filter
<b>Application:</b>	Cleaning guns with G1/2" female thread
<b>Material:</b>	Stainless steel
<b>Scope of delivery:</b>	1xG1/2" M Connector FOUR (AS) 1x 1/2" flat gasket
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.



## Accessories i3 FOUR

### Inline

<b>Designation:</b>	<b>G1/2" F Connector FOUR (AS)</b>
<b>Item number:</b>	2060061
<b>Description:</b>	Quick release coupling with G1/2" female thread AquaStopp function* included
<b>Compatibility:</b>	i3 FOUR inline filter
<b>Application:</b>	Cleaning guns with G1/2" male thread
<b>Material:</b>	Stainless steel
<b>Scope of delivery:</b>	1x G1/2" F Connector FOUR (AS) 1x G1/2" flat gasket
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel



\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.




## Accessories i3 FOUR

### Inline

<b>Designation:</b>	<b>Adaptor Lock</b>
<b>Item number:</b>	2060071
<b>Description:</b>	Safety device against unintentional activation of quick release coupling
<b>Compatibility:</b>	i3 FOUR inline filter G3/8" M Connector FOUR (AS)
<b>Application:</b>	Securing inline quick release couplings
<b>Material:</b>	ABS
<b>Scope of delivery:</b>	10 x adaptor lock





open



closed

## Accessories i3 FIVE






## Accessories i3 FIVE


### Inline

<b>Designation:</b>	<b>G3/8" M Connector FIVE (AS)</b>
<b>Item number:</b>	2060084
<b>Description:</b>	Quick release coupling with G3/8" male thread AquaStopp function* included
<b>Compatibility:</b>	i3 FIVE inline filter
<b>Application:</b>	RDG-E; birthing tubs; flex hoses with G1/2" female thread
<b>Material:</b>	POM (main body)
<b>Scope of delivery:</b>	1x G3/8" M Connector FIVE (AS)
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel



\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.







## Accessories i3 FIVE

### Inline

<b>Designation:</b>	<b>G1/2" M Connector FIVE (AS)</b>
<b>Item number:</b>	2060050
<b>Description:</b>	Quick release coupling with G1/2" male thread AquaStopp function* included
<b>Compatibility:</b>	i3 FIVE inline filter
<b>Application:</b>	RDG-E; birthing tubs; flex hoses with G1/2" female thread
<b>Material:</b>	POM (main body)
<b>Scope of delivery:</b>	1x G1/2" M Connector FIVE (AS)
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.




## Accessories i3 FIVE

### Inline

<b>Designation:</b>	<b>G1/2" F Connector FIVE (AS)</b>
<b>Item number:</b>	2060054
<b>Description:</b>	Quick release coupling with G1/2" female thread AquaStopp function* included
<b>Compatibility:</b>	i3 FIVE inline filter
<b>Application:</b>	RDG-E; birthing tubs; flex hoses with G1/2" male thread
<b>Material:</b>	POM (main body)
<b>Scope of delivery:</b>	1x G1/2" F Connector FIVE (AS)
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.




## Accessories i3 FIVE

### Inline

<b>Designation:</b>	<b>G3/4" M Connector FIVE (AS)</b>
<b>Item number:</b>	S206005
<b>Description:</b>	Quick release coupling with G3/4" male thread AquaStopp function* included
<b>Compatibility:</b>	i3 FIVE inline filter
<b>Application:</b>	RDG-E; birthing tubs; flex hoses with G3/4" female thread
<b>Material:</b>	POM (main body)
<b>Scope of delivery:</b>	1x G1/2" M Connector FIVE (AS) 1x G3/4" M Adaptor
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.




## Accessories i3 FIVE

### Inline

<b>Designation:</b>	<b>G3/4" F Connector FIVE (AS)</b>
<b>Item number:</b>	S206003
<b>Description:</b>	Quick release coupling with G3/4" female thread AquaStopp function* included
<b>Compatibility:</b>	i3 FIVE inline filter
<b>Application:</b>	RDG-E; birthing tubs; flex hoses with G3/4" male thread
<b>Material:</b>	POM (main body)
<b>Scope of delivery:</b>	1x G1/2" M Connector FIVE (AS) 1x G3/4" F Adaptor
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel




\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.



## Accessories i3 FIVE

### Inline

<b>Designation:</b>	<b>Wall Mount FIVE</b>
<b>Item number:</b>	2060052
<b>Description:</b>	Wall mount for the i3 FIVE
<b>Compatibility:</b>	i3 FIVE inline filter
<b>Application:</b>	Bracket for mounting i3 FIVE inline filter
<b>Material:</b>	Santopren (main body)
<b>Scope of delivery:</b>	1x Wall Mount FIVE 1x mounting kit
<b>Installation:</b>	Assembly and installation of the components must be carried out by qualified technical personnel



\*The AquaStopp function prevents unintentional water leakage when a filter is not installed.



## Overview of Accessories i3 ONE

i3 ONE Water tap		
Image	Designation	Item number
	M16 F Connector ONE (AS)	S206015
	M16.5 M Connector ONE (AS)	S206024
	M18 M Connector ONE (AS)	S206013
	M18.5 M Connector ONE (AS)	S206012
	M20 M Connector ONE (AS)	S206020
	M21.5 M Connector ONE (AS)	S206011
	M22 F Connector ONE (AS)	2060000
	M24 M Connector ONE (AS)	2060001
	M28 M Connector ONE (AS)	S206007
	Sampling Adaptor	S2060018

# Overview of Accessories

## i3 TWO

## i3 FOUR



i3 TWO Shower		
Image	Designation	Item number
A small black plastic connector with a white cap.	G1/2" M Connector TWO (AS)	2060002



i3FOUR Inline		
Image	Designation	Item number
A small metal connector with a threaded end.	G3/8" M Connector FOUR (AS)	2060005
A metal connector with a threaded end and a lock mechanism.	G1/2" M Connector FOUR (AS)	2060060
A metal connector with a threaded end and a lock mechanism.	G1/2" F Connector FOUR (AS)	2060061
A small metal ring or lock component.	Adaptor Lock	2060071

# Overview of Accessories

## i3 FIVE



i3 FIVE Inline		
Image	Designation	Item number
	G3/8" M Connector FIVE (AS)	2060084
	G1/2" M Connector FIVE (AS)	2060050
	G1/2" F Connector FIVE (AS)	2060054
	G3/4" M Connector FIVE (AS)	S206005
	G3/4" F Connector FIVE (AS)	S206003
	Wall Mount FIVE	2060052





i3 Membrane GmbH  
Christoph-Seydel-Str. 1  
DE-01454 Radeberg  
Germany

[www.i3membrane.de](http://www.i3membrane.de)  
[info@i3membrane.de](mailto:info@i3membrane.de)  
Tel: +49 (0)40-2576748-0  
Fax: +49 (0)40-2576748-48

Certification of quality  
management system  
as per DIN EN ISO 13485:201



Your Companion  
Life Science Filtration